

## Contents

---

- Open the color images and convert to grayscale
- Do some filtering
- Threshold the image
- scaling image color space

```
%Calvin and Keene Robotics Takehome
```

## Open the color images and convert to grayscale

---

```
cpens=imread('penguins.jpg'); %read in a file, convert to matlab matrices  
gpens=rgb2gray(cpens); %converts from color to grayscale  
imshow(cpens) %displays the image in a window  
figure  
imshow(gpens)
```





## Do some filtering

---


```
medpens= medfilt2(gpens, [3 3]); %median filters image (best to use after thresholding)
G = fspecial('gaussian',[3 3],2); %create 3x3 gaussian blur kernel
blurpens= imfilter(medpens,G,'same'); %filters image with gaussian blur (best to use before thresholding)
imshow(blurpens)
```




## Threshold the image

---

```
threshpens = calvthresh(blurpens,128);  
imshow(threshpens)  
%Morphological filtering  
se = strel('square',5); %creates a 5x5 kernel for morph. filtering  
erodedpens = imerode(threshpens,se); %erodes image (best to use afterthresholding)  
dilatedpens = imdilate(erodedpens,se); %dilates image (best to use afterthresholding)  
imshow(dilatedpens) %displays the image. imscale(dilatedpens) will be useful if you have images with pixel values outside the standard range, such as very large numbers after your segmentation labeling.  
%imsave %saves the current image
```



```
seg1 = calvseg(dilatedpens);  
seg2 = segim2(seg1);  
imagesc(seg2)  
colormap('gray')
```



## scaling image color space

---

```
%sometimes image processing takes the range of pixel values into a very smallrange, a very large  
% range or outside the typical range, including negative values. imagesc scales the pixel values  
%to within the normal range and displays it. It uses a default heatmap,  
%colormap, so change it to a gray color map.  
imagesc(test)
```

